

PERSONAL MICRO COMPONENT SYSTEM


MM-DT8

MM-DT8S

THIS APPLIANCE IS MANUFACTURED BY:



Instruction Manual













Safety Warnings

CLASS 1 LASER PRODUCT KLASSE 1 LASER PRODUKT LUOKAN 1 LASER LAITE KLASS 1 LASER APPARAT PRODUCTO LASER CLASE 1



RISK OF ELECTRIC SHOCK. DO NOT OPEN



CAUTION:

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE REAR COVER. NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

CLASS 1 LASER PRODUCT

This Compact Disc player is classified as a CLASS 1 LASER product.

Use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

CAUTION-INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCKS DEFEATED, AVOID EXPOSURE TO BEAM.



This symbol indicates that dangerous voltage which can cause electric shock is present inside this unit.



This symbol alerts you to important operating and maintenance instructions accompanying the unit.

WARNING: To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

Wiring the Main Power Supply Plug(UK Only)

IMPORTANT NOTICE

The main lead on this equipment is supplied with a moulded plug incorporating a fuse. The value of the fuse is indicated on the pin face of the plug and if it requires replacing, a fuse approved to BS1362 of the same rating must be used.

Never use the plug with the fuse cover removed. If the cover is detachable and a replacement is required, it must be of the same colour as the fuse fitted in the plug. Replacement covers are available from your dealer.

If the fitted plug is not suitable for the power points in your house or the cable is not long enough to reach a power point, you should obtain a suitable safety approved extension lead or consult your dealer for assistance.

However, if there is no alternative to cutting off the plug, remove the fuse and then safely dispose of the plug. Do not connect the plug to a main socket as there is a risk of shock hazard from the bared flexible cord.

Never attempt to insert bare wires directly into a main socket. A plug and fuse must be used at all times.

IMPORTANT

The wires in the main lead are coloured in accordance with the following code:-


BLUE = NEUTRAL BROWN = LIVE


As these colours may not correspond to the coloured markings identifying the terminals in your plug, proceed as follows:-

The wire coloured BLUE must be connected to the terminal marked with the letter N or coloured BLUE or BLACK. The wire coloured BROWN must be connected to the terminal marked with the letter L or coloured BROWN or RED.


WARNING: DO NOT CONNECT EITHER WIRE TO THE EARTH TERMINAL WHICH IS MARKED WITH THE LETTER E OR BY THE EARTH SYMBOL ______, OR COLOURED GREEN OR GREEN AND YELLOW.








Ensure that the AC power supply in your house complies with the identification sticker located on the back of your player. Install your player horizontally, on a suitable base (furniture), with enough space around it for ventilation (3-4inches). Make sure the ventilation slots are not covered. Do not stack anything on top of the player. Do not place the player on amplifiers or other equipment which may become hot. Before moving the player, ensure the disc tray is empty. This player is designed for continuous use. Switching off the DVD player to the stand-by mode does not disconnect the electrical supply. In order to disconnect the player completely from the power supply, remove the main plug from the wall outlet, especially when left unused for a long period of time.



During thunderstorms, disconnect AC main plug from the wall outlet.

Voltage peaks due to lightning could damage the unit.



Do not expose the unit to direct sunlight or other heat sources.


This could lead to overheating and malfunction of the unit.



Protect the player from moisture(i.e. vases), and excess heat(e.g.fireplace) or equipment creating strong magnetic or electric fields (i.e.speakers...). Disconnect the power cable from the AC supply if the player malfunctions. Your player is not intended for industrial use. Use of this product is for personal use only.

Condensation may occur if your player or disc have been stored in cold temperatures.

If transporting the player during the winter, wait approximately 2 hours until the unit has reached room temperature before using.



The battery used with this product contain chemicals that are harmful to the environment.

Do not dispose of batteries in the general household trash.



Multi-Disc Playback & AM/FM Tuner, TAPE

The MM-DT8/MM-DT8S combines the convenience of multi-disc playback capability, including DVD, VCD,CD,DivX,WMA, MP3-CD, CD-R, CD-RW, and DVD-RW, with a sophisticated AM/FM tuner, TAPE, all in a single player.

TV Screen Saver Function

The MM-DT8/MM-DT8S automatically brightens and darkens the brightness of the TV screen after 3 minutes in the stop .

Power Saving Function

The MM-DT8/MM-DT8S automatically shuts itself off after 20 minutes in the stop.

Customized TV Screen Display

The MM-DT8/MM-DT8S allows you to select your favorite image during JPEG, DVD playback and set it as your background wallpaper.



DVD (Digital Versatile Disc) offers fantastic audio and video, thanks to Dolby Digital surround sound and MPEG-2 video compression technology. Now you can enjoy these realistic effects in the home, as if you were in a movie theater or concert hall.





DVD players and the discs are coded by region. These regional codes must match in order for the disc to play. If the codes do not match, the disc will not play.

The Region Number for this player is given on the rear panel of the player. (Your DVD player will only play DVDs that are labeled with identical region codes.)


Copy Protection

- Many DVD discs are encoded with copy protection. Because of this, you should only connect your DVD player directly to your TV, not to a VCR. Connecting to a VCR results in a distorted picture from copy-protected DVD discs.
- This product incorporates copyright protection technology that is protected by methods claims of certain
 U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights
 owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and
 is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision
 Corporation. Reverse engineering or disassembly is prohibited.




	PREPARATION	
	Safety Warnings	
	Precautions	
	Features	
	Description	5
	CONNECTIONS	
	Connecting the Speakers	
	Connecting to a TV	
	Connecting External Components	
(Connecting the FM and AM(MW) Antennas	12
	Setting the Clock.	
	OPERATION	
	Disc Playback	15
	Mp3/WMA-CD Playback	
	DivX Playback	
	Displaying Disc Information	
	Fast/Slow Playback	
	Skipping Scenes/Songs	
	Angle Function	
F	Repeat Playback	23
A	A-B Repeat Playback	25
7	Zoom Function	26
5	Selecting Audio/Subtitle Language	27
1	Moving Directly to a Scene/Song	28
	JPEG File Playback	
	Using Disc Menu	
0	Using the Title Menu	32
	SETUP	
	Setting the Language	
	Language Code List	
	Setting TV Screen type	
	Setting Parental Controls (Rating Level)	37
	Setting the Password	
	Setting the Wallpaper	
	Setting the DRC (Dynamic Range Compression)	
	USB	42
	Playing USB	13
	Selecting a Track from USB Device.	
	To use high speed search	
	RADIO OPERATION	
	Listening to Radio	46
	Presetting Stations	
	About RDS broadcasting	
	TAPE DECK	
L	Listening to a Cassette Selecting the cassette Playback Mode/Repeat A↔B Function	50
_ 5	Selecting the cassette Playback Mode/Repeat A↔B Function	51
_	MISCELLANEOUS	
	Timer Function	
	Canceling the Timer	
	Recording a Compact Disc	
	Recording a Radio Program	
	DSP/EQ/Sound Mode/Treble/Bass Function Function	
	Sleep Timer Function / Mute FunctionDEMO / DIMMER Function	
	Connecting Headphones	
	Cautions on Handling and Storing Discs	
	Before Calling for Service	
	Notes on Terminology	
	Specifications	
	JSB Feature Supported Player	
•	·	

Description Front Panel—




- 1. USB/AUX
- 2. FUNCTIONS (DVD/CD/TUNER/TAPE)
- 3. STANDBY/ON
- 4. CD SYNCHRO / REC/PAUSE
- 5. SEARCH FUNCTION BUTTONS
 TUNING MODE OR STOP BUTTON
- 6. USB JACK

- 7. HEADPHONE JACK CONNECTOR
- 8. CD DOOR OPEN/CLOSE
- 9. DSP/EQ
- 10. P.SOUND
- 11. VOLUME CONTROL
- 12. MULTI JOG/PUSH ENTER




Accessories



Description The company of the comp

-Remote Control-




Insert Remote Batteries

Remove the battery cover on the back of the remote by pressing down and sliding the cover in the direction of the arrow.



2 Insert two 1.5V AAA batteries, paying attention to the correct polarities (+ and –).



Replace the battery cover.



Caution

Follow these precautions to avoid leaking or cracking cells:

- ullet Place batteries in the remote control so they match the polarity:(+) to (+)and (-)to (-).
- Use the correct type of batteries.Batteries that look similar may differ in voltage.
- · Always replace both batteries at the same time.
- · Do not expose batteries to heat or flame.

Range of Operation of the Remote Control


The remote control can be used up to approximately 23 feet/7 meters in a straight line. It can also be operated at a horizontal angle of up to 30° from the remote control sensor.





Connecting the Speakers

Before moving or installing the product, be sure to turn off the power and disconnect the power cord.



Position of the DVD Player

 Place it on a stand or cabinet shelf, or under the TV stand.

Loudspeakers **D**R

- Place these speakers in front of your listening position, facing inwards (about 45°) toward you.
- Place the speakers so that their tweeters will be at the same height as your ear.

Selecting the Listening Position

The listening position should be located about 2.5 to 3 times the distance of the TV's screen size away from the TV. Example: For 32" TVs 2~2.4m (6~8feet)
For 55" TVs 3.5~4m (11~13feet)


Directions in Installing Speaker

- Installation in a place near heating apparatus, under direct lay of light or with high humidity may cause performance degradation of the speaker.
- Do not install on the wall or on a high place of pole or other unstable place to prevent any safety accident caused by falling of the speaker.
- Do not take the speaker apart from TV or computer monitor.
 The speaker near the TV or computer monitor may influence the quality of the screen display.



Connecting to a TV

Please be sure to turn off the power and unplug the power cord before moving or installing this unit. Please choose one of three video connection methods.



METHOD 1 Composite Video Good Quality

Connect the supplied video cable from the VIDEO OUT jack on the back panel of the system to the VIDEO IN jack on your television.

METHOD 2 Scart Better Quality

If your television is equipped with an SCART input, connect an Scart Jack (not supplied) from the AV OUT jack on the back panel of the system to the SCART IN jack on your television.

VIDEO SELECT Function

Press and hold VIDEO SEL. button on the remote control for over 5 seconds.

- "COMPOSITE" or "RGB" will appear in the display.
 At this time, press the VIDEO SEL. button shortly to select between "COMPOSITE" and "RGB".
- If Scart (RGB Input) is equipped for your TV, press VIDEO SEL. button to select RGB mode.
 You can get a better picture quality by using Scart setting.
- If Scart (RGB Input) is not equipped for your TV, press VIDEO SEL. button to select COMPOSITE mode.


METHOD 3 Component (Progressive Scan) Video Best Quality

Use this method if your TV have Pr,Pb,and Y jacks.

If your television is equipped with Component Video inputs, connect a component video cable (not supplied) from the Pr, Pb and Y jacks on the back panel of the system to the corresponding jacks on your television.




 When the Progressive scan mode is selected, the VIDEO output (Yellow) and SCART output does not output any signal.



Connecting to External Components

Connecting to an External Analog Component


Example: Analog signal components such as a VCR, Camcorder, and TV.



- Connect Audio In on the DVD player to Audio Out on the external analog component.
 Be sure to match connector colors.
- Press AUX to select AUX.

 'AUX' appears in the display.

Connecting the FM and AM(MW) Antennas



FM antenna connection

- 1. Connect the FM antenna supplied to the FM 75Ω COAXIAL terminal as a temporary measure.
- Slowly move the antenna wire around until you find a location where reception is good, then fasten it to a wall or other rigid surface.
- If reception is poor, connect an outdoor antenna. Before attaching a 75 Ω coaxial cable (with a standard type connector), disconnect the supplied FM antenna.

AM(MW) antenna connection

- 1. Connect the AM loop antenna supplied to the AM and \dot{m} terminals.
- If reception is poor, connect an outdoor single vinyl-covered wire to the AM terminal. (Keep the AM loop antenna connected).

PSCAN(Progressive Scan) Function

ke regular Interlace Scan, in which two fields of picture information alternate to create the entire picture (odd scan lines, then even scan lines). Progressive Scan uses one field of information (all lines displayed in one pass) to create a clear and detailed picture without visible scan lines.

Press STOP button.

• If playing a disc, press the STOP button twice so that "STOP", appears on the display.

Press and hold P.SCAN button on the remote control for over 5 seconds.

- Pressing and holding the button for over 5 seconds will select "Progressive Scan" and "Interlace Scan" alternately.
- When you select P.SCAN, "P.SCAN" will appear on the display.
- · To set P.Scan mode for DivX discs, press the P.SCAN button on the remote control for more than 5 seconds with no disc in the unit ("NO DISC" on the display), then load the DivX disc and play.

What is Progressive (or Non-Interlaced) Scanning?

Interlaced Scan (1 FRAME = 2 FIELDS)

In interlaced-scan video, a frame consists of two interlaced fields (odd and even), where each field contains every other horizontal line in the frame. The odd field of alternating lines is displayed first, and then the even field is displayed to fill in the alternating gaps left by the odd field to form a single frame. One frame, displayed every 1/25th of a second, contains two

interfaced fields, thus a total of 50 fields are displayed every 1/50th of a second. The interlaced scanning method is intended for capturing a still object.

Progressive Scan (FULL FRAME)



The progressive scanning method scans one full frame of video consecutively down the screen, line by line. An entire image is drawn at one time, as opposed to the interlaced scanning process by which a video image is drawn in a series of passes.

The progressive scanning method is desirable for dealing with moving objects.

- Note This function works only on TVs equipped with component video inputs (Y, Pr, Pb) that support Progressive Video. (It does not work on TVs with conventional component inputs, i.e., non-progressive
 - Depending on the capabilities of your TV, this function may not work.



Setting the Clock

For each step, you have a few seconds to set the required options. If you exceed this time, you must start again.

Switch the system on by pressing **POWER** button

Press TIMER/CLOCK twice

CLOCK is displayed.

Press ENTER. The hour flashes.

• Increase the hours :)

• Decrease the hours : (

When the correct hour is displayed. press ENTER. The minutes flash.

• Increase the minutes :) • Decrease the minutes : (()

When the correct time is displayed, press ENTER.

• "TIMER" appears in the display.

. The current time is now set.

Note

· You can display the time, even when you are using another function, by pressing TIMER/CLOCK once.

Selecting the Video Format

Turn off the main unit and then press and hold NT/PAL button on the remote controller for over 5 seconds .


- . By default, the video format is set to "PAL".
- . "NTSC" and "PAL" will appear in the display. At this time, press the NT/PAL button shortly to select between "NTSC" and "PAL".
- · Each country has a different video format standard.
- For normal playback, the video format of the disc must be the same as the video format of your TV.


Checking the Remaining Time

Press the REMAIN button.

• For checking the total and remaining time of a title or chapter being played.

Each time the REMAIN button is pressed





Disc Playback



MP3/WMA-CD Playback

Data CDs (CD-ROM, CD-R, CD-RW) encoded in MP3/WMA format can be played.



press STOP during playback.

. If pressed once, "PRESS PLAY" is displayed and the

stop position will be stored in memory. If PLAY/PAUSE

(| button or ENTER button is pressed, playback

resumes from the stop position. (This function works

Press OPEN/CLOSE button to open the disc trav.

Load a disc.

· Place a disc gently into the tray with the disc's label

Press OPEN/CLOSE button to close the disc tray.



· Playback starts automatically.



- Playback starts automatically.
- . If the TV is on, a list of MP3s on the CD will appear on the TV



Note

- Depending on the content of the disc, the initial screen may appear different.
- Depending on the recording mode, some MP3-CDs cannot be played.
- Table of contents of a MP3-CD varies depending on the MP3 track format recorded on the disc.

To temporarily pause playback, press PLAY/PAUSE during playback.

· To resume playback, press PLAY/PAUSE button again.



Press the **OPEN/CLOSE** button to open the disc tray. and then load the MP3/WMA disc.

- The MP3/WMA menu screen will appear and playback will start.
- The appearance of the menu depends on the MP3/WMA disc.
- WMA-DRM files cannot be played.



A Let It Be € Select El es

In Stop mode, use

★ ▼ to select

press the **ENTER**

button.

Use ▲ ▼to select the track.

the album, and then

To change the album, use **♦** ▶ **★** ▼to select another album in Stop mode, and then press the **ENTER** button.

· To select another album and track, repeat Steps 2 and 3 above.

Press the STOP button to stop playback.

- . Depending on the recording mode, some MP3/WMA-CDs may not play.
- Table of contents of a MP3-CD varies depending on the MP3/WMA track format recorded on the disc.

To play a file icon in the screen,

Press the ◀ ▶ ▲ ▼button when it is in stop status and select a desired icon from the top part of the menu.

- To play music files only, select the **[**] Icon.
- To view image files only, select the loon.
- To view movie files only, select the III Icon.
- To select all files select the All Icon.



- · Music File Icon
- Image File Icon Movie File Icon
- · All File Icon

· If pressed twice, "STOP" is displayed, and if PLAY/PAUSE () button is pressed, playback starts from the beginning.

only with DVDs.)

DivX Playback

Skip Forward/Back


During playback, press the I◀◀ ▶►I button.

- Go to the next file whenever you press ►►I button, if there are over 2 files in the disk
- Go to the previous file whenever you press I◄◀ button, if there are over 2 files in the disk.

Fast playback

Press ◆◆ ▶ button.

 Each time the button is pressed during playback, the playback speed changes as follows:



Zoom Function


Press **ZOOM** button.

• Each time you press the button, your selection will toggle between "ZOOM X2" and "ZOOM OFF".

Press Cursor ▲, ▼,
◀, ▶ buttons to
move to the area
you want to enlarge.

DivX files can be played in

Zoom X2 mode only.



5 Minute Skip function

During playback, press the ◀, ▶ button.

- Go to the screen about 5 minutes after whenever you press ▶ button.
- Go to the screen about 5 minutes earlier whenever you press ■ button.

- Audio Display

Press the AUDIO button.

- If there are multiple audio tracks on a disc, you can toggle between them.
- Each time you press the button, your selection will toggle between "AUDIO(1/1, 1/2 ...)" and "



" (M)

Subtitle Display

Press the **SUBTITLE** button.

- Each time you press the button, your selection will toggle between "SUBTITLE ON" and "SUBTITLE OFF".
- If the disc has only one subtitle file, it will be played automatically.
- Up to 8 subtitle languages are supported.

If the disc has more than one subtitle file

If the disc has more than one subtitle file, the default subtitle may not match the movie and you will have to select your subtitle language as follows:

In Stop mode, press the ▲, ▼, ◀, ▶ button, select the desired subtitle (🖃) from the TV screen, and then press the **ENTER** button.

2 When you select the desired DivX file from the TV screen, the movie will be played normally.

DivX Feature Table

DivX Supported

Avi files are used to contain the audio and video data; these must be stored on CD in the ISO 9660 format.

		SPEC
VIDEO Compatibility	DivX3.11	Up to the latest VERSION
AUDIO Compatibility	MP3	CBR: 80kbps~320kbps
	AC3	CBR: 128kbps~448kbps
	WMA	CBR: 56kbps~160kbps

MPEGs containing DivX can be divided into Video and Audio.

- Video compatibility: All versions of DivX later than 3.11 (including the latest 5.1) are supported. In addition, XviD is supported.
- Audio compatibility: MP3s encoded at bitrates from 80kbps to 320kbps, AC3s from 128kbps to 448kbps are supported.
- In addition, for subtitles, this unit will support Text format (SMI).

Not

- Note When playing the DivX disk, you can play the file with extension of AVI only.
 - Among the available DivX audio formats, DTS Audio is not supported.
 - When burning a subtitle file to a CD-ROM with your PC, be sure to burn it as an SMI file.

Displaying Disc Information

You can view playback information on the disc on the TV screen.



Press **INFO** button


• Each time the button is pressed, the display changes as follows:







Display disappears



Note

· Depending on the disc, the disc information display may appear different.

. What is a Title?

A movie contained in a DVD disc.

· What is a Chapter?

Each title on a DVD disc is divided into several smaller sections called "chapters".

appears on the TV screen!

If this symbol appears on the TV screen while buttons are being operated, that operation is not possible with the disc currently being played.

. What is a Track (File)?

A section of video or a music file recorded on a VCD, CD, or MP3-CD.

Screen Display

DVD DVD display










VCD VCD display








· Each time the button is pressed during playback, the playback speed changes as follows:



Slow Playback

Press **SLOW** button.

 Each time the button is pressed during playback. the playback speed changes as follows:





Skipping Scenes/Songs



DVD) (TUNER) (TAPE) (AUX)

(H) (II)

(A)

9

(h/II) (h)







Briefly press I◀◀ ▶▶I button.

- Each time the button is pressed briefly during playback, the previous or next chapter, track, or directory (file) will be played.
- · But, you cannot skip chapters consecutively.

















. When watching a VCD with a track longer than 15 minutes, each time is pressed, playback will skip back or forward 5 minutes.










Playing Frame by Frame DVD



Press STEP button.

• The picture moves forward one frame each time the button is pressed during playback.



Note

- During fast playback of a CD or MP3-CD, sound is heard only at 2x speed, and not at 4x, 8x, and 32x speeds.
- No sound is heard during slow playback and step motion playback.



Press **INFO** button.



Press Cursor ▶ button to move to ANGLE display.

Press Cursor ▲, ▼ buttons or numeric buttons to select the desired angle.

• Each time the button is pressed, the angle changes as follows:











• The Angle function works only with discs on which multiple angles have been recorded.





REPEAT : OFF

• Each time the button is pressed during playback, the repeat playback mode changes as follows:



Repeat Playback Options

CHAPTER

Repeatedly plays the selected chapter.

TITLE

Repeatedly plays the selected title.

RANDOM

Plays tracks in random order.
(A track that has already been played may be played again.)

TRACK

Repeatedly plays the selected track.

DIR

Repeatedly plays all tracks in the selected folder.

DISC

Repeatedly plays the entire disc.

OFF


Cancels Repeat Playback.





To Select a Repeat Playback Mode in the Disc Information Screen





Note

 For MP3 and JPEG discs, you cannot select Repeat Play from the information display screen.

A-B Repeat Playback



This function allows you to enlarge a particular area of the displayed image.

DVD VCD CD

Press **REP. A**↔**B** at the beginning of the section you want to repeat.

REPEAT : A-

Press REP. A↔B at the end of the section.



To cancel AB Repeat Playback, press REP. A↔B to select "REPEAT PLAYBACK: OFF".



Note

- A-B Repeat Playback does not work on MP3 and JPEG discs.
 A-B repeat playback does not work in USB mode.too.
- To select AB Repeat Playback from the information display screen, press REP. A⇔B button.



Zoom (Screen Enlarge) Function




Press **ZOOM** button.

ENTER ZOOM



Press ENTER button.

• Each time the button is pressed, the zoom level changes as follows:




♣ Aspect Ratio



Press **EZ VIEW** button.

- Each time the button is pressed, the zoom function will switch between On and Off.
- When a movie is played in Widescreen format, black bars at the top and bottom of the TV screen can be removed by pressing the EZ VIEW button



Note

- . This function will not work if the DVD is recorded with multi-camera angle format.
- Black bars may not disappear because some DVD discs have a built-in horizontal to vertical ratio.

And the state of t

Selecting Audio/Subtitle Language

Press **INFO** button twice.

DVD PE EN 1/3 PRESS - OFF/ 02 COFF

Press Cursor A, V
buttons or numeric
buttons to select the
desired audio language.

 Depending on the number of languages on a DVD disc, a different audio language (KOREAN, ENGLISH, JAPANESE, etc.) is selected each time the button is pressed.



You can use the Audio button on the remote control to select a Audio language.

Subtitle Language Selection Function

Press **INFO** button



Press Cursor ► button to move to SUBTITLE display.



Press Cursor ▼
button or numeric
buttons to select
the desired subtitle.

twice.



Note

- You can use the SUBTITLE button on the remote control to select a subtitle
- Depending on the disc, the Subtitle and Audio Language functions may not work.



Moving Directly to a Scene/Song

DVD VCD CD

Press **INFO** button.



Moving to a Title/Track

Press Cursor ▲, ▼ buttons or numeric buttons to select the desired title/track and then press ENTER button.



Moving to a Chapter

Press Cursor ∢, ► buttons to move to Chapter display.



Moving to a Chapter

Press Cursor ▲, ▼ buttons or numeric buttons to select the desired chapter and then press ENTER button.



Moving to a Specific Time

Press Cursor∢, ► buttons to move to time display.



Moving to a Specific Time

Press the numeric buttons to select the desired time and then press **ENTER** button.



MP3 JPEG

Press the **numeric** buttons.

- The selected file will be played.
- An MP3 or JPEG disc cannot be moved from the disc information screen.
- When playing an MP3 or JPEG disc, you cannot use ▲ ,▼ to move a folder.
 To move a folder, press (Stop) and then press ▲ ,▼ .



Note

- You can press I◄◄►►I on the remote control to move directly to the desired title, chapter, or track.
- Depending on the disc, you may not be able to move to the selected title or time.
- As for VCD Version 2.0 disk, you can use TIME Search function in PBC OFF mode.



Images captured with a digital camera or camcorder, or JPEG files on a PC can be stored on a CD and then played back with this DVD player.


Slide Mode

Place the JPEG disc on the disc tray.

Press the OPEN/CLOSE button.

Press SLIDE MODE button.

- Playback starts automatically.
- Each time the button is pressed, the image makes the transition as follows:



From top to bottom

From bottom to top

Rectangular shape in the center

Vertical curtain shape

Each time a new image is displayed, slide modes (1~11) will be randomly and automatically be applied.

Cancels the slide mode.



Press I◄◀ ▶►I to skip to the next slide.

• Each time the button is pressed, the slide moves backward or forward.

Digest Function

You can view 9 JPEG images on the TV screen.

Press **DIGEST** button during playback.

 JPEG files will be shown in 9 windows.



- Press Cursor ▲, ▼, ◀, ▶ buttons to select the desired image and then press **ENTER** button.
- The selected image is played for 5 seconds before moving to the next image.






To view the previous or next image with 9 windows, press ◄◄.▶► .

Rotate/Flip Function

Press Cursor ▲, ▼, ◀, ▶ buttons during playback.





Using Disc Menu

You can use the menus for the audio language, subtitle language, profile, etc. DVD menu contents differ from disc to disc.

Press Cursor ▲ .▼

buttons to move to

'DISC MENU' and then

press ENTER button. . When you select the disc menu that is not

supported by the disc, the "This menu is not

supported" message appears on the screen.



- Press **MENU** button in the stop mode.
- When playing a VCD (version 2.0), this toggles between PBC ON and OFF.



Press Cursor ▲, ▼, ◀, ▶ buttons to select the desired item.



Press ENTER button.





Note

PBC (Playback Control) Function

When playing a VCD (version 2.0), you can select and view various scenes according to the menu screen.

PBC ON: This VCD disc is version 2.0. The disc is played back according to the menu screen. Some functions may be disabled. When some functions are disabled, select "PBC OFF" to enable them


PBC OFF: This VCD disc is version 1.1. The disc is played back in the same way as with a music CD.



For DVDs containing multiple titles, you can view the title of each movie. Depending on the disc, this function may either not work at all or may work differently.

DVD

♣ Press MENU button in the stop mode.



Press ENTER button.

• The title menu appears.





• You can use the Title Menu button on the remote control to select Title Menu

Press MENU button to exit the setup screen.



Setting the Language

OSD language is set to English by default.

Press **MENU** button in the stop mode.



Press Cursor ▲,▼
button to select the
desired item and then
press ENTER button.



Press Cursor ▼
button to move to
'Setup' and then
press ENTER button.



Press Cursor A, V
button to select the
desired language and then
press ENTER button.

 Once the setup is complete, if the language was set to English, OSD will be displayed in English.



Press ENTER button.



Note

 To select other language, select OTHER and enter the language code of your country.

(See 34 page for language code of countries)

AUDIO, SUB TITLE and DISC MENU language can be selected.





Selecting the OSD Language



Selecting the Audio Language (recorded on the disc)



Selecting the Subtitle Language (recorded on the disc)



Selecting the Disc Menu Language (recorded on the disc)

* If the language you selected is not recorded on the disc, menu language will not change even if you set it to your desired language

Press RETURN button to return to the previous level.

Press MENU button to exit the setup screen.



Language Code List

Enter the appropriate code number for the initial settings "Disc Audio", "Disc Subtitle" and/or "Disc Menu" (See page 31).

Code	Language	Code	Language	Code	Language	Code	Language
1027	Afar	1181	Frisian	1334	Latvian, Lettish	1506	Slovenian
1028	Abkhazian	1183	Irish	1345	Malagasy	1507	Samoan
1032	Afrikaans	1186	Scots Gaelic	1347	Maori	1508	Shona
1039	Amharic	1194	Galician	1349	Macedonian	1509	Somali
1044	Arabic	1196	Guarani	1350	Malayalam	1511	Albanian
1045	Assamese	1203	Gujarati	1352	Mongolian	1512	Serbian
1051	Aymara	1209	Hausa	1353	Moldavian	1513	Siswati
1052	Azerbaijani	1217	Hindi	1356	Marathi	1514	Sesotho
1053	Bashkir	1226	Croatian	1357	Malay	1515	Sundanese
1057	Byelorussian	1229	Hungarian	1358	Maltese	1516	Swedish
1059	Bulgarian	1233	Armenian	1363	Burmese	1517	Swahili
1060	Bihari	1235	Interlingua	1365	Nauru	1521	Tamil
1069	Bislama	1239	Interlingue	1369	Nepali	1525	Tegulu
1066	Bengali; Bangla	1245	Inupiak	1376	Dutch	1527	Tajik
1067	Tibetan	1248	Indonesian	1379	Norwegian	1528	Thai
1070	Breton	1253	Icelandic	1393	Occitan	1529	Tigrinya
1079	Catalan	1254	Italian	1403	(Afan) Oromo	1531	Turkmen
1093	Corsican	1257	Hebrew	1408	Oriya	1532	Tagalog
1097	Czech	1261	Japanese	1417	Punjabi	1534	Setswana
1103	Welsh	1269	Yiddish	1428	Polish	1535	Tonga
1105	Danish	1283	Javanese	1435	Pashto, Pushto	1538	Turkish
1109	German	1287	Georgian	1436	Portuguese	1539	Tsonga
1130	Bhutani	1297	Kazakh	1463	Quechua	1540	Tatar
1142	Greek	1298	Greenlandic	1481	Rhaeto-Romance	1543	Twi
1144	English	1299	Cambodian	1482	Kirundi	1557	Ukrainian
1145	Esperanto	1300	Kannada	1483	Romanian	1564	Urdu
1149	Spanish	1301	Korean	1489	Russian	1572	Uzbek
1150	Estonian	1305	Kashmiri	1491	Kinyarwanda	1581	Vietnamese
1151	Basque	1307	Kurdish	1495	Sanskrit	1587	Volapuk
1157	Persian	1311	Kirghiz	1498	Sindhi	1613	Wolof
1165	Finnish	1313	Latin	1501	Sangro	1632	Xhosa
1166	Fiji	1326	Lingala	1502	Serbo-Croatian	1665	Yoruba
1171	Faeroese	1327	Laothian	1503	Singhalese	1684	Chinese
1174	French	1332	Lithuanian	1505	Slovak	1697	Zulu

Setting TV Screen type



Press **MENU** button in the stop mode.



Press Cursor ▼
button to move to
'Setup' and then
press ENTER button.



Press Cursor ▼
button to move to 'TV
DISPLAY' and then
press ENTER button.



Press Cursor ▲,▼
button to select the
desired item and then
press ENTER button.

 Once the setup is complete, you will be taken to the previous screen.



Adjusting the TV Aspect Ratio (Screen Size)

The horizontal to vertical screen size ratio of conventional TVs is 4:3, while that of wide screen and high definition TVs is 16:9. This ratio is called the aspect ratio. When playing DVDs recorded in different screen size, you should adjust the aspect ratio to fit your TV or monitor.

* For a standard TV, select either "4:3LB" or "4:3PS" option according to personal preference. Select "16:9" if you have a wide screen TV.



- : Select this to view a 16:9 picture in the full-screen mode on your wide screen TV.
- · You can enjoy the wide screen aspect.



4:3LB (4:3 Letter box)

- Select this to play a 16:9 picture in the letter box mode on a conventional TV.
- Black bars will appear at the top and bottom of the screen.



4:3PS (4:3 Pan&Scan)

- Select this to play a 16:9 picture in the pan & scan mode on a conventional TV.
- You can see the central portion of the screen only (with the sides of the 16:9 picture cut off).



Note

- If a DVD is in the 4:3 ratio, you cannot view it in wide screen.
- Since DVD discs are recorded in various image formats, they will look different depending on the software, the type of TV, and the TV aspect ratio setting.

Press **RETURN** button to return to the previous level.

Press **MENU** button to exit the setup screen.

Setting Parental Controls (Rating Level)

Use this to restrict playback of adult or violent DVDs you do not want children to view.



Press **MENU** button in the stop mode.

Press Cursor V button to move to 'Setup' and then press **ENTER** button.

Press Cursor V button to move to 'PARENTAL' and then press ENTER button.







Press Cursor ▲. ▼ button to select the desired rating level and then press **ENTER** button.

- If you have selected Level 6, you cannot view DVDs with Level 7 or
- . The higher the level, the closer the content is to violent or adult material.



Enter the password and then press **ENTER** button.

- The password is set to "7890" by default. . Once the setup is complete, you will be
- taken to the previous screen.



. This function works only if a DVD disc contains the rating level information.

Press **MENU** button in the stop mode.



Press Cursor ▼ button to move to 'Setup' and then press ENTER button.



Press Cursor ▼ button to move to 'PASSWORD' and then press **ENTER** button.



Press **ENTER** button.



Enter the password and then press **ENTER** button.

· Enter the old password, a new password, and confirm new password.

. The setting is complete.



Note

• The password is set to "7890" by default.

Press **RETURN** button to return to the previous level.

Press **MENU** button to exit the setup screen.

Press CANCEL button to cancel the error numeric when you inputting password.

Using the RESET function will erase all stored settings.

- While the player is in the no disc mode, hold the main unit's TUNING MODE/ button for longer than 5 seconds. "INITIALIZE" appears on the display and all settings will return to the default values.
- · Press the POWER button.







While watching a DVD, VCD, or JPEG CD, you can set the image you like as a wallpaper.

Setting the Wallpaper

During playback, press PLAY/PAUSE button when the image you like comes up.



Press LOGO button.


• "LOGO COPY DATA" will be displayed on the TV screen.



The power will turn off and then back on and will play the disc tray automatically.

• The selected wallpaper will be displayed.





in the stop mode.



Press Cursor ▼ button to move to 'Setup' and then press **ENTER** button.



Press Cursor ▼ button to move to 'LOGO' and then press ENTER button.



Press ▼ to select the desired 'USER', and then press ENTER.



Press **MENU** button to exit the setup screen.



Select this to set the Samsung Logo image as your wallpaper.



Select this to set the desired image as your wallpaper.

Press RETURN button to return to the previous level.

Press MENU button to exit the setup screen.

distribution of the state of th

Setting the DRC (Dynamic Range Compression)

You can use this function to enjoy Dolby Digital sound when watching movies at low volume at night.



Video may look slower than the audio if it is connected with digital TV.

In this case, adjust the delay time of audio to optimal status to fit the video.



Press **MENU** button in the stop mode.

Press Cursor ▼ button to move to 'Audio' and then press ENTER button.



Total Manual

AMOD

Total Manual

AMOSTNC : Omisee

AMOSTNC : Omisee

AMOSTNC : Omisee

AMOSTNC : Omisee

If "DRC" is selected, press ENTER.

Press Cursor ▲ ,▼ to adjust the 'DRC'.

 The Cursor ▲ button is pressed, the greater the effect, and the Cursor ▼ button is pressed, the smaller the effect.



Press the **MENU** button in the stop mode.

· Setup menu appears.



- Press Cursor ▲, ▼ buttons to move to 'AV-SYNC' and then press **ENTER** button.
- · AV-SYNC screen appears.



Press Cursor ▲, ▼ buttons to move to 'Audio' and then press ENTER button.

· 'Audio' menu appears.



- Press Cursor ▲ ,▼ buttons to select the Delay Time of AV-SYNC and then press the ENTER button.
- You can set the audio delay time between 0 ms and 300 ms. Set it to the optimal status.



Press RETURN button to return to the previous level.

Press MENU button to exit the setup screen.

Press **RETURN** button to return to the previous level.

Press **MENU** button to exit the setup screen.


41



Playing USB

You can play MP3 files by connecting to various external USB storage devices such as USB flash memory or HDD. time.

Connect the external **USB** storage device to your player.



- The first track of the first directory plays automatically.
- Do not connect USB charging device to the USB connection port of the player, because it may cause damage to the product.



Press the Stop () button to stop playing.

 Press the Stop () button once to pause, and press the button twice to stop completely.

Please be aware of the following before using USB.

- · Depending on the type of external USB storage device, it may not work even if it's connected to the player.
- · With external HDD, FAT format can be played, but not NTFS format.
- With USB 2.0 HDD, connect to a separate power source.
- If it's not connected to a separate power source, it may not work.
- If memory of an external USB storage device is segmented into several parts, MP3 files of only the first hard disk drive can be played.
- · Regarding directories, up to fourth directory can be played.
- DRM applied files are not played.
- Digital Rights Management: Technology and service that protect the profit and rights of copyright owners by disallowing unauthorized use of digital contents.
- Even if the file name ends with .mp3, the file does not play if actual file format is MPEG layer 1 or 2.
- Disconnect the external USB storage device only in safe removal mode("USB REMOVE" display ON/OFF).
 Otherwise, internal file can be damaged.

Press the Stop (■) button more than 3 times to get into the safe removal mode.

If you want to play files in the safe removal mode, disconnect and reconnect the external USB storage device.

- · USB hub will not be recognized.
- Directory names are shown up to 14 letters, and MP3 file names up to 30 letters.

Delay

- When selecting USB function, depending of the speed of the external USB storage device, reading (READ-IN) internal
 information can take several minutes.
- When playing a USB device, recording or finding next track may introduce some delay. Especially with a mass storage device such as HDD, depending on the type and the number of files, the delay might be several minutes.
- Even with the external USB storage devices of same capacity, depending on the speed of each product, the amount of operating time can vary.
- If the external USB storage device supports only USB VER 1.1 and the access speed is slow, the recording may not
 work well or noise can be recorded.
 - The USB function of this product does not support all USB devices.
 For the information on the supported devices,pls see the page 67.



Selecting a Track from USB Device

You can select a desired directory and an MP3 file during the play or when it stopped.

- **Before you begin!** ♦ Connect the external USB storage device to your player.
 - Select USB function by using the USB button.

Press the Cursor ▲ ,▼ buttons to move the directory.

- Each time you press the button, it will move to the directory before or after.
- . This function works only in the remote control.

If you want to move the file, press the ⋈, ⋈ button shortly.

- . It moves the file within the directory.
- If you press the id, button more times than the number of the files in the directory, it will move over to the next directory.







To use high speed search

Before you begin! ◆ Connect the external USB storage device to your player.
◆ Select USB function by using the USB button.

You can search the part you want quickly during the play

Press the ◄ , ▶ button.

- Whenever you press the button, you can search backward or forward 2X → 4X → 8X → 32X
- → OFF times quickly.
- When you use the high speed search function (4X,8X,32X) , there is no sound.

>> To repeat

Press the **REPEAT** button during the play.

- REPEAT RANDOM: Plays tracks in random order.

 (A track that has already been played may be played again.)
- REPEAT 1 : repeat play one track only.
- . REPEAT Dir : repeat play the folder .
- . REPEAT ALL: repeat play the entire directories.



Listening to Radio

You can listen to the chosen band (FM, AM broadcast stations) by using either the automatic or manual tuning operation.

Remote Control Unit

Press TUNER/BAND button.

Tune in to the desired station.

Automatic Tuning 1 Press the STOP (■) or Tuning

Mode button to select PRESET and
then press ♠️ button to select the preset station.

Automatic Tuning 2 Mode button to select "AUTO" and then press ⊘ button to automatically search the band.

Manual Tuning Press the STOP (■) or Tuning Mode button to select"MANUAL".Briefly press

to increase or decrease the frequency incrementally.

Main Unit

Press the Function button to select the desired band (FM/AM).

2 Select a broadcast station.

Automatic Tuning 1
Press the STOP () Tuning Mode button to select © PRESET and then press button to select the preset station.

Automatic Tuning 2 Press the STOP (■) or Tuning Mode button to select "AUTO" and then press ♦ button to automatically search the band.

Manual Tuning Press STOP (■) or Tuning Mode to select MANUAL and then briefly press ♦♦ to tune in to a lower or

briefly press 🛇 🔾 higher frequency.



Press MO/ST button to listen in Mono/Stereo.

(This applies only when listening to an FM station.)

- Each time the button is pressed, the sound switches between "STEREO" and "MONO".
- In a poor reception area, select MONO for a clear, interference-free broadcast.

Presetting Stations You can store up to:

- ♦ 15 FM stations
- ♦ 15 AM stations

.. Frequency Modulation

· AM(MW) ···· ··· Medium Wave

Example: Presetting FM 89.1 in the memory

Press the **TUNER(BAND)** button and select the FM band

Press 🛇 🗘 to select "89 10"

• Refer to Step 2 on page 46 to

to a station.

automatically or manually tune in

Press the **TUNER MEMORY** button.


Press (to select preset number.

· You can select between 1 and 15.

Press the TUNER **MEMORY** button.

- . Press the TUNER MEMORY button before 'PRGM' disappears from the display.
- . 'PRGM' disappears from the display and the station is stored in memory.

To tune in to a preset station, press () on the remote control to select a channel



To preset another station, repeat steps 2 to 5.

Using the RDS (Radio Data System) to receive FM stations

About RDS broadcasting

RDS allows FM stations to send an additional signal along with their regular program signals. For example the stations send their station names as well as information about what type of program they broadcast, such as sports or music etc.

When tuned to an FM station which provides the RDS service, the RDS indicator lights up on the display.

- · Description on RDS function
- 1. PTY (Program Type): Displays the type of programmer currently being broadcast
- 2. PS NAME (Program Service Name): Indicates the name of broadcasting station and is composed of 8 characters.
- 3. RT (Radio Text): Decodes the text broadcast by a station (if any) and is composed of maximum 64 characters.
- 4. CT (Clock Time): Decodes the real time clock from the FM frequency.
- Some stations may not transmit PTY, RT or CT information therefore this may not be displayed in all cases.
- 5. TA (Traffic Announcement): When this symbol flashes it shows that the traffic announcement is in progress.

 RDS may not operate correctly if the station tuned is not transmitting RDS signal properly or if the signal strength is weak.

What information can RDS signals provide?

You can see the RDS signals the station sends on the display.

TO show the RDS signals

Press RDS DISPLAY while listening to an FM station.

Each time you press the button, the display change to show you the following information:

→ PS NAME → RT → CT → Frequency -

PS (Program Service): While searching, "PS" appears and then the station names will be displayed."NO PS" appears if no signal is sent.

RT(Radio Text): while searching, "RT" appears and then text messages the station sends will be displayed. "NO RT"appears if no signal is sent.

Frequency: station frequency (non-RDS service)

About characters shown in the display

When the display shows PS, or RT signals, the following characters are used.

- The display window cannot differentiate upper case and lower case letters and always uses upper case letters.
- The display window cannot show accented letters, "A," for instance, may stand for accented "A's" like "A. A. A. A. Aand A."

• If searching finishes at once, "PS", and "RT" will not appear on the display.

(A) (h) (USB) (5) (6) TIMER MENORY PISCAN

PTY (Program Type) indication and PTY-SEARCH function

One of the advantages of the RDS service is that you can locate a particular kind of program from the preset channels by specifying the PTY codes.

To search for a program using the PTY codes


Before you start, remember...

- The PTY Search is only applicable to preset stations.
- To stop searching any time during the process, press PTY SEARCH while searching.
- There is a time limit in doing the following steps.
 If the setting is cancelled before you finish, start from step 1 again.
- When pressing the buttons on the primary remote control, make sure that you have selected the FM station using the primary remote control.
- Press PTY SEARCH while listening to an FM station.
- Press the PTY-or PTY+until the PTY code you want appears on the display.
 - The display gives you the PTY codes described to the right.
- Press PTY SEARCH again, while the PTY code selected in the previous step is still on the display.
 - The center unit searches 15 preset FM stations, stops when it finds the one you have selected, and tunes in that station.

	Display	Program Type
•	NEWS	News including an announced opinion and report
-	AFFAIRS	Several matters including a current incident, documentary, discussion and analysis.
_	INFO	Information including weights and measures, returns and forecast, matters interesting the customer, medical information, etc.
-	SPORT	• Sports
-	EDUCATE	• Education
-	DRAMA	Drama-Radio serial, etc.
, -	CULTURE	Culture-National or local culture including the religious problem, social science, language, theater,etc.
Ī	SCIENCE	Natural science and technology
_	VARIED	Others-Speech, amusing program (quiz, game), interview, comedy and satirical play, etc.
	POP M	Pop music
-	ROCK M	• Rock music
	M.O.R.M	Current contemporary music considered to be "easy listening."
Ī	LIGHT M	Light classical music- Classical music and instrumental and chorus music
symp		Heavy classical music-Orchestra music, symphony, chamber music and opera
	OTHER M	Other music - Jazz, R&B country music
_	WEATHER	• Weather
Ī	FINANCE	• Finance
Ī	CHILDREN	Children's programmers
Ī	SOCIAL A	Social affairs
Ī	RELIGION	• Religion
Ī	PHONE IN	• Phone in
Ī	TRAVEL	• Travel
_	LEISURE	• Leisure
	JAZZ	Jazz Music
	COUNTRY	Country Music
	NATION M	National Music
Ī	OLDIES	Oldies Music
Ī	FOLK M	• Folk Music
	DOCUMENT	Documentary



Always treat your cassettes with care; refer, if necessary, to the section entitled "Precautions When Using Audio Cassettes" on page 61.





Switch the system on by pressing **POWER**.

Press TAPE on the player to select the Tape function.

Press the PUSH
EJECT (♠) of the
cassette deck to open
the cassette door and
insert a cassette.

 Insert a cassette with the recording/playback side facing the cassette holder, and then push the cassette door shut.

Press the ► button or ►/II on the remocon. The cassette starts playing.

- Side A : Tape (◀►) button once.
- Side B : Tape (◄►) button twice.

Press the | ◄ ◄ , ▶ ► |
buttonor ◄ ■ , ▶ ► |
button on the remocon if
necessary.

- Rewind the cassette I◄◄ / DOWN button.
- Fast-forward the cassette UP / ▶▶I button.

When you have finished playback, press STOP button.

MISCELLANEOUS

Selecting the cassette Playback **Mode/Repeat A↔B Function**

Selecting the Cassette Playback Mode

Your micro component system has three cassette playback modes which enable you to listen to both sides of a cassette automatically.

Press REV.MODE until the appropriate symbol is displayed.

•When the display indicates...The micro component system plays back

One side of the selected cassette and then stops.

One side of the cassette The other side of the cassette and then stops.

Both sides of the cassette indefinitely until

you press stop

REPEAT A↔B Function

Press **REP.** A↔B button

- Use this to listen to a specific section again during playback.
- Set the start and end points of the section you want to repeat 3 times.
- This is a useful when learning a foreign language.
- The TAPE REPEAT function can be used only on sections that are longer than 7 seconds.



· You cannot set the end point (B) within 7 seconds after setting the start point (A)



Timer Function

The timer enables you to switch the system on or off at specific times.

- If you no longer want the system to be switched on or off automatically, you must cancel the timer.
- Before setting the timer, check that the current time is correct.
- For each step, you have a few seconds to set the required options. If you exceed this time, you must start again,

Example: You wish to wake up to music every morning.

Switch the system on by pressing POWER

Press TIMER/CLOCK until TIMER is displayed.

Press the **ENTER** button.

. ON TIME is displayed (instead of the equalizer symbols) for a few seconds, followed by any switch-on time already set; you can set the timer switch-on time.

Set the timer switch-on time

- a. Set the hour by pressing ◀ or ▶ button.
- b. Press ENTER.
- The minutes flash.
- c. Set the minutes by pressing ◀ or ▶ button
- d. Press ENTER.
- . OFF TIME is displayed (instead of the equalizer symbols) for a few seconds, followed by any switchoff time already set: you can now set the timer switch-off time.

Set the timer switch-off time.

- a. Set the hour by pressing ◀ or ▶
- b. Press ENTER.
- The minutes flash.
- c. Set the minutes by pressing ◀ or ▶ button
- d. Press ENTER.
- VOL 20 is displayed, where 20 corresponds to the volume already set.

Press ◀ or ▶ button to adjust the volume level and press ENTER.

. The source to be selected is displayed.

Press ◀ or ▶ button to select the source to be played when the system switches on.

- . TAPE (cassette): Insert a cassette
- TUNER (radio) : a Press ENTER. **b** Select a preset station by pressing Tuning dor
- CD (compact disc): Load a compact
- USB : Connec the usb

Press ENTER to confirm the timer.

- Press **POWER** to set the system to standby mode.
- () is displayed to the top-right of the time, indicating that the timer has been set.
- . The system will switch on and off automatically at the required times.

Note

• If the timer switch on and off times are identical, the word ERROR is displayed.

(4) (5) (6) (8) (9) (H4) (III) J ZOOM SLDE MODE DIGEST TUSING THE NEXTON REPARE LOGO EZVIEW DEMO NTIPAL (DIMER) TIMER ONOFF TIMERICLOCK SLEEP

To cancel the timer, press **TIMER ON/OFF** once.

• ① is no longer displayed.

To resume the timer, press **TIMER ON/OFF** again.

• ① is displayed again.

Note

• You can cancel the timer while the power is on or while the player is in standby

Synchronized recording

This feature enables you to synchronize the start of the recording with the start of the disc or track of your choice.



Switch the system on by pressing **POWER**.

- 2 Insert a blank cassette in Deck.
- Press the PUSH/EJECT button (
)
 to open the cassette door, insert a
 cassette, and then close the cassette
 door.
- Insert the cassette with the safety tabs.
- 3 Load a compact disc.
- Press the OPEN/CLOSE button (▲) to open the CD door.
- Insert a CD and press the OPEN/CLOSE button (▲) to close the CD door.

- Press the **DVD/CD** (▶/**||**) button.
- Use the CD selection (I◄◀, ▶▶I) buttons to select the desired song.
- **5** Press and hold CD SYNC. button.
- When stopped, press the button to start the recording from the first piece of music.
- Press and hold CD SYNC. button during the playback of CD to start the recording from the first part of the music being played.
- 6 To stop recording, press button.

Note


- Treble, Bass, DSP/EQ, and Power sound function don't work during the recoding.
- Synchronized recording Function is available for CD only.

Recording a Radio Program

You can record a radio program of your choice.
You do not need to adjust the volume, as it has no effect on the recording.

Direct recording

The direct recording mode enables you to start recording with any track on the compact disc.



- Switch the system on by pressing **POWER**.
- 2 Insert a blank cassette in Deck.
- Press the PUSH/EJECT button (▲) to open the cassette door, insert a cassette, and then close the cassette door.
- Insert the cassette with the safety tabs.
- 3 Load a compact disc.
- Press the OPEN/CLOSE button (▲) to open the CD door.
- Insert a CD and press the OPEN/CLOSE button (▲) to close the CD door.

- Press the DVD/CD (►/II) button.
- Use the CD selection (I◄◄, ▶►I) buttons to select the desired song.
- 5 Press REC/ PAUSE button.
- Recording will begin.
- To stop recording, press button.

Note

• The cassette tape you want to record on must have the safety tabs intact.



Switch the system on by pressing **POWER**.

2 Insert a blank cassette in Deck.

Select the TUNER function by pressing TUNER/BAND.


- Select the radio station that you wish to record by pressing | <-/p>
- 5 Press REC/PAUSE button.
- REC is displayed in red and recording starts.

To stop recording, press ■ button.

DSP/EQ/Sound Mode/Treble/Bass Function

Your micro component system is equipped with a preset equalizer that allows you to choose the most appropriate balance between treble and bass frequencies, according to the type of music you are listening to.

The function of Power Sound amplifies bass and improves high key or bass twice as much for vou to appreciate powerful real sound.



DSP/EQ Function

Press P.SOUND button until the

Press DSP/EQ control until the required option is selected.

 Press the button repeatedly to select "PASS→POPS→ JAZZ-ROCK-STUDIO-CLUB-HALL-MOVIE-CHURCH→PASS"

required option is selected.

- Press the button repeatedly to select "S.BASS→P.SOUND".
- . S.BASS Function: S.Bass function emphasizes the bass sound to produce the effect of explosion or booms.

Selecting SOUND MODE

 P.SOUND Function: You can experience the powerful. and realistic sound by amplifying bass and improving the sound quality of high- and low-pitched sounds by two-fold.

Treble Level Function Bass Level Function

thudding sound effects.

Treble Control function stresses high tones providing

BASS function stresses low tones providing thudding sound effects.

Press MULTI JOG(PUSH ENTER) button until TREB 00 is displayed.

- Turn MULTI JOG(PUSH ENTER) knob to select from TREB -18 to TREB 18.
- •You can select the level of high tones you desire.

Press MULTI JOG(PUSH ENTER) button until BASS 00 is displayed.

- Turn MULTI JOG(PUSH ENTER) knob to select from BASS -18 to BASS 18.
- You can select the level of low tones you desire.

Sleep Timer Function / Mute Function

Sleep Timer Function

You can set the time that the DVD player will shut itself off.

Press **SLEEP** button.

• Each time the button is pressed, the selection changes as follows: 90 MIN \rightarrow 60 MIN \rightarrow 45 MIN \rightarrow 30 MIN \rightarrow 15 MIN \rightarrow SLEEP OFF.

90MIN

To confirm the sleep timer setting, press **SLEEP** button.

- •The remaining time before the DVD player will shut itself off is displayed.
- Pressing the button again changes the sleep time from what you have set

To cancel the sleep timer, press SLEEP button until **SLEEP** OFF appears on the display.

Mute Function

This is useful when answering a doorbell or telephone call.

Press **MUTE** button.

- 'MUTE' appears in the display.
- . To turn off mute, press the button again.







You can connect a set of headphones to your micro component system so that you can listen to music or radio programmers without disturbing other people in the room. The earphones must have a 3.5ø jack or an appropriate adapter.



You can view the various functions available on your system.

Press **DEMO/DIMMER** button.

- The various functions available are listed in turn on the display.
- All these functions are described in detail in this booklet.
 For instructions on how to use them, refer to the appropriate sections.




You can adjust the brightness of the display on the main unit so it won't interfere with your movie viewing.

Press **DEMO/DIMMER** button.

 Each time the button is press, the brightness changes as follows: DEMO→DIMMER ON(Dim) → DIMMER OFF(Bright).

To cancel this function, press **DEMO/DIMMER** again.







Connect the headphones to the $\mbox{\sc PHONES}$ jack on the front panel.

• The loudspeakers are no longer used to output the sound.

Note

• Prolonged use of headphones at a high volume may damage your hearing.

Cautions on Handling and Storing Discs

Small scratches on the disc may reduce sound and picture quality or cause breaks in playback. Be especially careful not to scratch discs when handling them.





Do not touch the playback side of the disc. Hold the disc by the edges so that fingerprints will not get on the surface.

Do not stick paper or tape on the disc.

Handling and Storing Discs



When you get fingerprints or dirt on the disc, clean it with a mild detergent diluted in water and wipe with a soft cloth.

• When cleaning, wipe gently from the inside to the outside of the disc.



 Condensation may form if warm air comes into contact with cold parts inside the player. When condensation forms inside the player, the player may not operate correctly. If this occurs, remove the disc and let the player stand for 1 or 2 hours with the power on.

Precautions When Using Audio Cassettes

- · Check that the tape in the cassette is sufficiently taut.
- To prevent erasing a cassette that you wish to keep, remove the safety tab on the upper edge of the
 cassette. To record a cassette, where the tab has been broken, simply cover the opening with adhesive
 tape.
- · When you have finished playing a cassette, always put it back in its case.
- Store your cassettes in a clean place, out of direct sunlight, where they will not be exposed to high temperatures.
- · Avoid using 120-minute cassettes as they place unnecessary strain on the tape mechanism.







Before Calling for Service

Fefer to the chart below when this unit does not function properly. If the problem you are experiencing is not listed below or if the instruction below does not help, turn off the unit, disconnect the power cord, and contact the nearest authorized dealer or Samsung Electronics Service Center.

Symptom	Check/Remedy
Disc tray does not open.	Is the power cord plugged securely into the outlet? Turn off the power and then turn it back on.
Playback does not start.	Check the region number of the DVD. DVD discs purchased from abroad may not be playable. CD-ROMs and DVD-ROMs cannot be played on this DVD player. Make sure that the rating level is correct.
The remote control does not work.	Is the remote control being operated within its operation range of angle and distance?Are the batteries exhausted?
Playback does not start immediately when the Play/Pause button is pressed.	Are you using a deformed disc or a disc with scratches on the surface? Wipe the disc clean.
Sound is not produced.	 No sound is heard during fast playback, slow playback, and step motion playback. Are the speakers connected properly? Is the speaker setup correctly customized? Is the disc severely damaged?
Picture does not appear, sound is not produced, or the disc tray opens 2 to 5 seconds later.	Was the DVD player suddenly moved from a cold place to a warm one? When condensation forms inside the player, remove the disc and let the player stand for 1 or 2 hours with the power on. (You can use the player again after condensation disappears.)
 Disc is rotating but no picture is produced. Picture quality is poor and picture is shaking. 	 Is the TV power on? Are the video cables connected properly? Is the disc dirty or damaged? A poorly manufactured disc may not be playable.



Symptom	Check/Remedy
Audio language and subtitles do not work.	Audio language and subtitles will not work for DVDs not containing them. And depending on the disc, they may work differently.
Menu screen does not appear even when the menu function is selected.	Are you using a disc that does not contain menus?
Aspect ratio cannot be changed.	You can play 16:9 DVDs in 16:9 WIDE mode, 4:3 LETTER BOX mode, or 4:3 PAN SCAN mode, but 4:3 DVDs can be seen in 4:3 ratio only. Refer to the DVD disc jacket and then select the appropriate function.
The tape does not start playing	 The TAPE function has not been selected. The cassette has not been inserted correctly. The cassette player has not been closed. The tape is either slack or broken.
The volume falls off The cassette is not erased correctly There is excessive wow and flutter	The audio heads are dirty. The rollers or drive capstans are dirty. The tape is worn.
Can't receive radio broadcast.	Is the antenna connected properly? If the antennas input signal is weak, install an external FM antenna in an area with good reception.
The main unit is not working. (Example: The power goes out or strange noise is heard.) The DVD player is not working normally.	Turn off the power and hold the STOP button on the main unit for longer than 5 seconds. Using the RESET function will erase all stored settings. Do not use this unless necessary.
The password for rating level has been forgotten.	While the player is in the stop mode, hold the main unit's TUNING MODE/ button for longer than 5 seconds. "INITIAL" appears on the display and all settings will return to the default values. Press the POWER button. Using the RESET function will erase all stored settings. Do not use this unless necessary.

Disc Recording Format

CD-R Discs

- Depending on the disc recording device (CD-Recorder or PC) and the condition of the disc, some CD-R discs may not be playable.
- Use a 650MB/74 minute CD-R. Avoid CD-R media, as they may not be playable.
- If possible, do not use CD-RW (Rewritable) media, as they may not be playable.
- Only the CD-Rs that are properly "closed" can be fully played. If the session is closed but the disc is left open, you may not be able to fully play the disc.

CD-R MP3 Discs

- Only CD-R discs with MP3 files in ISO 9660 or Joliet format can be played.
- MP3 file names should be 8 characters or less in length and contain no blank spaces or special characters (. / = +).
- If the name of a file is in Korean, the name will be displayed on the TV screen in Korean and * will be shown in the display of the main unit.
- Use discs recorded with a compression/decompression data rate greater than 128Kbps.
- Only files with the ".mp3" and ".MP3" extensions can be played.
- Only a consecutively written Multisession disc can be played. If there is a blank segment in the Multisession disc, the
 disc can be played only up to the blank segment.
- If the disc is not closed, it will take longer to begin playback and not all of the recorded files may be played.
- For files encoded in Variable Bit Rate (VBR) format, i.e. files encoded in both low bit rate and high bit rate (e.g., 32Kbps ~ 320Kbps), the sound may skip during playback.
- If more than 500 tracks are recorded on a single CD, a maximum of 500 tracks can be played.
- If more than 300 folders are recorded on a single CD, a maximum of 300 folders can be played.

What is MP3?

MP3 is short for MPEG-1 Audio Layer 3 and MPEG is an acronym for Moving Pictures Experts Group. MP3 is a file format with compression ratio of 1:12 (128 Kbps*) That is, you can use MP3 format to record about 12 times the usual amount of data on a regular CD.

CD-R JPEG Discs

- Only files with the ".jpeq" and ".JPEG" extensions can be played.
- If the disc is not closed, it will take longer to start playing and not all of the recorded files may be played.
- Only CD-R discs with JPEG files in ISO 9660 or Joliet format can be played.
- JPEG file names should be 8 characters or less in length and contain no blank spaces or special characters (. / = +).
- Only a consecutively written multisession disc can be played. If there is a blank segment in the multisession disc, the
 disc can be played only up to the blank segment.
- A maximum of 9,999 images can be stored on a single CD.
- When playing a Kodak/Fuji Picture CD, only the JPEG files in the picture folder can be played.
- Picture discs other than Kodak/Fuji Picture CDs may take longer to start playing or may not play at all.

Notes on Terminology



ANGLE	Recorded onto some DVD discs are scenes which have been simultaneously shot from a number of different angles (the same scene is shot from the front, from the left , from the right , etc.). With such discs, the Angle button can be used to change the angle of view for specific scenes.
CHAPTER NUMBER	These numbers are recorded on DVD discs. A Title is subdivided into many sections, each of which is numbered, and specific parts of the video can be searched quickly using these numbers.
DVD	A high-density optical disc on which high-quality pictures and sound have been recorded by means of digital signals. Incorporating a new video compression technology (MPEG-2) and high-density recording technology, a DVD disc comprises two 0.6 mm thick discs bonded together.
PCM	An acronym for Pulse Code Modulation - another name for digital audio.
PBC (PLAYBACK CONTROL)	This is recorded on a video CD (version 2.0). Selected scenes or information can be chosen from the menu displayed on the TV monitor.
REGION NUMBER	Both the DVD player and DVD discs are encoded with a region number. If the region number on the DVD disc does not correspond to the region number of the DVD player, the player cannot play the disc.
SUBTITLES	Translated appearing at the bottom of the screen. A DVD disc can contain up to 32 subtitle languages.
TITLE NUMBER	These numbers are recorded on DVD discs. When a disc contains two or more movies, these movies are numbered as Title 1, Title 2, etc.
TRACK NUMBER	These numbers are assigned to the tracks which are recorded on video and audio CDs. They enable specific tracks to be located quickly.
VIDEO CD	Contains recordings of pictures and sound whose quality is roughly comparable to that of video tape. This player also supports video CDs with playback control (version 2.0).
DOLBY	5.1 (or 6) Channel Digital Surround sound reproduced from DVDs and LDs recorded as a digital signals (with DIGITAL disc marking). With better sound quality, dynamic range, and directionality than traditional Dolby surround technology, you can enjoy dynamic, realistic sound.

	Weight	2.7Kg		
GE NE	Dimensions (W x H x D)	170 x 232 x 332 mm		
RA	Operating Temperature Range	+5°C~+35°C		
L	Operating Humidity Range	10%~75%		
F U	Usable Sensitivity	3dB		
F UN M E	S/N Ratio	60dB		
<u>R</u>	Distortion	1.0%		
AM U	Usable Sensitivity	56dB		
Ň E R	S/N Ratio	40dB		
<u>R</u> _	Distortion	2%		
	Composite Video	1.0Vp-p(75Ω load)		
VIDEO	Component Video	Y : 1.0Vp-p(75Ω load)		
OUTPUT	Component video	Pr : 0.7Vp-p(75Ω load)		
		Pb : 0.7Vp-p(75Ω load)		
A	Speaker output	2X40W		
AMP LIFIER	Frequency range	20Hz~20kHz		
Ī	S/N Ratio	75dB		
į	Channel separation	50dB		
Ē	Input sensitivity	(AUX)500mV		
	Impedance	4Ω x 2		
S	Frequency range	20 Hz - 20 KHz (± 1 dB)		
P	Output sound pressure level	84dB/W/M		
E	Rated input	40W		
A	Maximum input	80W		
K E	Dimensions (W x H x D)	145(W) x 233 (H) x 205(D) mm		
R	Weights	4.1 Kg		

USB Feature Supported Player

If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care center.

Digital Camera

Fuji	Digital Camera
Fuji	Digital Camera
Konica	Digital Camera
Kyocera	Digital Camera
Minolta	Digital Camera
Minolta	Digital Camera
Minolta	Digital Camera
Nikon	Digital Camera
Olympus	Digital Camera
Panasonic	Digital Camera
Pentax	Digital Camera
Samsung	Digital Camera
Samsung	Digital Camera
Toshiba	Digital Camera
Nikon	Digital Camera
Nikon	Digital Camera
Nikon	Digital Camera
Panasonic	Digital Camera
Minolta	Digital Camera
Olympus	Digital Camera
	Fuji Fuji Fuji Fuji Konica Kyocera Kyocera Kyocera Kyocera Kyocera Minotta Minotta Minotta Minotta Mikon Nikon Panasonic Panasonic Panasonic Panasonic Panasonic Panasonic Panasonic Panasonic Nasonic Pentax Pentax Pentax Pentax Pentax Nikon Nikon Nikon Nikon Nikon Nikon Panasonic Panasonic

USB Flash Disk

Product	Company	Туре
Cruzer Micro	Sandisk	USB 2.0 USB Flash Drive 128M
Cruzer Mini	Sandisk	USB 2.0 128M
Cruzer Mini	Sandisk	USB 2.0 256M
SONY Micro Vault	Sony	USB 2.0 64MB
FLEX DRIVE	Serotech	USB 2.0 32MB
AnyDrive	A.L tech	USB 2.0 128MB
XTICK	LG	USB 2.0 128M
Micro Mini	Iomega	USB 2.0 128M
iFlash	Imation	USB 2.0 64M
LG	XTICK(M)	USB 2.0 64M
RiDATA	EZDrive	USB 2.0 64M

MP3 Player

Product	Company	Туре
Creative MuVo NX128M	Creative	128 MB MP3 Player
Iriver H320	Iriver	20G HDD MP3 Player
YH-920	Samsung	20G HDD MP3 Player
YP-T7	Samsung	MP3 Player
YP-MT6	Samsung	MP3 Player
YP-T6	Samsung	MP3 Player
YP-53	Samsung	MP3 Player
YP-ST5	Samsung	MP3 Player
YP-T5	Samsung	MP3 Player
YP-60	Samsung	MP3 Player
YP-780	Samsung	MP3 Player
YP-35	Samsung	MP3 Player
YP-55	Samsung	MP3 Player
iAUDIO U2	Cowon	MP3 Player
iAUDIO G3	Cowon	MP3 Player
iAudio M3	Cowon	HDD MP3 Player
SI-M500L	Sharp	256MB MP3 Player
H10	Iriver	MP3 Player
YP-T5 VB	Samsung	MP3 Player
YP-53	Samsung	256MB MP3 Player

Multi Card Reader

Product	Company	Туре
UNICORN	Unicorn	USB 2.0 7 IN 1 CARD READER UC-601R
USB 2.0 Card Reader	Billionton(Taiwan)	USB 2.0 Card Reader for SD/MMC/RS-MMC(3-in-1)

USB External HDD

	Product	Company	Туре	
CUTIE MOMOBAY UX-2		Serotech	POCKET HARD DISK DRIVE	
		Dvico	USB 2.0	

Region	Country	Customer Care Center 2	Web Site
	CANADA	1-800-SAMSUNG (7267864)	www.samsung.com/ca
North America	MEXICO	01-800-SAMSUNG (7267864)	www.samsung.com/mx
	U.S.A	1-800-SAMSUNG (7267864)	www.samsung.com
	ARGENTINE	0800-333-3733	www.samsung.com/ar
	BRAZIL	0800-124-421	www.samsung.com/br
	CHILE	800-726-7864(SAMSUNG)	www.samsung.com/cl
	COSTA RICA	0-800-507-7267	www.samsung.com/latin
	ECUADOR	1-800-10-7267	www.samsung.com/latin
	EL SALVADOR	800-6225	www.samsung.com/latin
Lordon American	GUATEMALA	1-800-299-0013	www.samsung.com/latin
Latin America	JAMAICA	1-800-234-7267	www.samsung.com/latin
	PANAMA	800-7267	www.samsung.com/latin
	PUERTO RICO	1-800-682-3180	www.samsung.com/latin
	REP. DOMINICA	1-800-751-2676	www.samsung.com/latin
	TRINIDAD & TOBAGO	1-800-7267-864	www.samsung.com/latin
	VENEZUELA	1-800-100-5303	www.samsung.com/latin
	BELGIUM	02 201 2418	www.samsung.com/be
	CZECH REPUBLIC	844 000 844	www.samsung.com/cz
	DENMARK	38 322 887	www.samsung.com/dk
	FINLAND	09 693 79 554	www.samsung.com/fi
	FRANCE	08 25 08 65 65 (0,15€/Min)	www.samsung.com/fr
	GERMANY	01805 - 121213 (€ 0,12/Min)	www.samsung.de
	HUNGARY	06 40 985 985	www.samsung.com/hu
	ITALIA	199 153 153	www.samsung.com/it
_	LUXEMBURG	02 261 03 710	www.samsung.lu
Europe	NETHERLANDS	0900 20 200 88 (€ 0.10/Min)	
	NORWAY		www.samsung.com/nl
		231 627 22	www.samsung.com/no
	POLAND PORTUGAL	0 801 801 881	www.samsung.com/pl
		80 8 200 128	www.samsung.com/pt
	SLOVAKIA	0850 123 989	www.samsung.com/sk
	SPAIN	902 10 11 30	www.samsung.com/es
	SWEDEN	08 585 367 87	www.samsung.com/se
	U.K	0870 242 0303	www.samsung.com/uk
CIS	RUSSIA	8-800-200-0400	www.samsung.ru
	UKRAINE	8-800-502-0000	www.samsung.com/ur
	AUSTRALIA	1300 362 603	www.samsung.com/au
	CHINA	800-810-5858, 010- 6475 1880	www.samsung.com.cn
	HONG KONG	2862 6001	www.samsung.com/hk
	INDIA	3030 8282	www.samsung.com/in
		1600 1100 11	
	INDONESIA	0800-112-8888	www.samsung.com/id
Asia Pacific	JAPAN	0120-327-527	www.samsung.com/jp
	MALAYSIA	1800-88-9999	www.samsung.com/my
	PHILIPPINES	1800-10-SAMSUNG (7267864)	www.samsung.com/ph
	SINGAPORE	1800-SAMSUNG (7267864)	www.samsung.com/sg
	THAILAND	1800-29-3232	www.samsung.com/th
		02-689-3232	
	TAIWAN	0800-329-999	www.samsung.com/tw
Middle East & Africa	VIETNAM	1 800 588 889	www.samsung.com/vn
madic Last a Allica	SOUTH AFRICA	0860 7267864 (SAMSUNG)	www.samsung.com/za
	U.A.E	800SAMSUNG (7267864)	www.samsung.com/mea

- EUROPE ONLY -

This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract.

This product should not be mixed with other commercial wastes for disposal.

